

**PART #121205 / #121205-12**  
**SINGLE ARCTIC HUT®**  
**PARTS LIST / INSTALLATION INSTRUCTION SHEET**

<u>PART#</u>	<u>DESCRIPTION</u>	<u>10' Unit</u> <u>QTY.</u>	<u>12' Unit</u> <u>QTY.</u>
AH101	44.75" Arc w/connector	6	6
AH103	44.75" Arc no connector	2	2
AH104	36.667" Side w/connector	4	0
AH105	36.667" Side no connector	2	0
AH106	40" Front/back no connector	2	2
AH107	Corner piece with hitch pin	4	4
AH122	Ground anchor stake	4	4
AH111	42.5" Spreader bar w/Velcro straps	3	3
AH116	44.75" Side w/connector	0	4
AH117	44.75" Side no connector	0	2
AH118	24" Extension w/connector	0	2
AH114	Canvas cover (10 ft)	1	0
AH113	Canvas cover (12 ft)	0	1
AH115	Single Hut Installation Package	1	1



## INSTALLATION INSTRUCTIONS

1. Install 2 CORNER pieces to 40" END BASE pieces, being sure Velcro faces UP, and Hitch Pin holes are outside/in. (*Figure A*)



A.

2. Install first, one SIDE BASE (2 - 36.667" w/connector, 1 - 36.667" no connector) to END PIECE, keeping Velcro UP. Then install second side piece, completing the base
3. Install ARCH pieces (4 per side). HINT – put 3 pieces on FRONT CORNER piece, the fourth on the REAR CORNER piece, THEN connect them. (*Figure C&D*)

(*Figure C*)



C.



D.

4. Install Canvas appropriately over Frame, while Frame is upright.

5. Lay Frame on one side and attach Velcro Flaps to corners only. (Figure E & F)



E.



F.

6. Lay Hut on other side and install Velcro flaps. (Figure G) Ding the corners first, then the center. Return to other side and finish installing flaps.



G.

**HINT**

SIDE A: Attach CORNERS only.

SIDE B: Install Center Flaps first, set on pavement, madly BEAT Canvas, THEN lift up and install corner Velcro. Then go to Side A and install Middle Flaps

**TO INSTALL ON TRAILER**

1. Set into desired position on trailer, keeping it against the trailer side rail.
2. Drill 11/32" holes for Hitch Pins in the side rail of the trailer. (*Figure H*)



H.

3. Mark location of Anchor/Hinge in the trailer center and install with self-tapping screws provided. (*Figure I*)



I.

## **FOR GROUND INSTALLATION**

1. Set HUT onto desired location.
2. Drive tent Anchor/Hinge into the ground, lining up the Hitch Pin holes with the Hitch Pin in the HUT.

**USE** – On a trailer, or on the ground, once properly installed the HUT may be opened from either end for easy entry/exit.

## **WARNING**

**DO NOT EXCEED 65 MPH WHILE TRAILERING THIS HUT!**



January 13, 2006

## **ADDITIONAL INSTRUCTIONS**

For 12' Arctic Hut

- **FRAME ASSEMBLY:** Follow same instructions as 10' for the base assembly.
- **ARCH ASSEMBLY:** Use Four ARCH pieces, as per 10' Unit but at the top, install the two-foot additional piece. **HINT:** Be sure the Two-foot piece with the buckle is in the center Arch and the buckle is on TOP.

---

## **CONSUMER FEEDBACK REQUESTED:**

Commercial Sewing needs your input as to how this HUT works. This is very important to us. Please call, fax or email your comments on the performance of your Arctic Hut to:

Phone: 1-860-482-5509  
Fax: 1-860-482-7964  
[ceo@commercialsewing.com](mailto:ceo@commercialsewing.com)

---

**WARRANTY INFORMATION:**

This product has been warranty-furnished as a "TEST PRODUCT". It is unconditionally guaranteed for one year, against defect in material and workmanship. Warranty is limited to replacement only.

For any questions or comments regarding warranty, please contact:

Scott Gordon  
Commercial Sewing, Inc.  
860-482-5509 x137

**CAUTION:**  
**DO NOT EXCEED 65 MPH WITH THIS UNIT**

**PARTS CHECK LIST  
SINGLE ARCTIC HUT  
#121205 / #121205-12**

<b><u>PART#</u></b>	<b><u>DESCRIPTION</u></b>	<b><u>10' Unit QTY.</u></b>	<b><u>12' Unit QTY.</u></b>
AH101	44.75" Arc w/connector	6	6
AH103	44.75" Arc no connector	2	2
AH104	36.667" Side w/connector	4	0
AH105	36.667" Side no connector	2	0
AH106	40" Front/back no connector	2	2
AH107	Corner piece with hitch pin	4	4
AH122	Ground anchor stake	4	4
AH111	42.5" Spreader bar w/Velcro straps	3	3

AH116	44.75" Side w/connector	0	4
AH117	44.75" Side no connector	0	2
AH118	24" Extension w/connector	0	2
AH114	Canvas cover (10 ft)	1	0
AH113	Canvas cover (12 ft)	0	1
AH115	Single Hut Installation Package	1	1