

# ARCTIC CAT<sup>®</sup>

## ATV FENDER COVER

Check for the following parts before beginning installation:

1 Instruction sheet, 1 Fender Cover & Pod cover, 6 Tree clips

## INSTALLATION INSTRUCTIONS

Remove the seat, as per instruction manual.

Place the cover on the machine so that the warning labels are readable from the driver's seat.

Release all the velcro on the cover.

Work the front of the cover underneath the front rack and place the pockets under the front portion of the fenders.

On the outside bottom corners located near the footwells & wheels attach pockets to fenders.

Place the gear shifter through the appropriate hole in the cover.

Work the rear of the cover underneath the rear rack.

Attach all the velcro on the cover to itself. Butt the material, do not overlap the edge material adjust it so that it lays flat!

Be sure the pocket (that grabs the very front of the center body panel) is cupping the plastic.

Attach all the "J" clips around the cover to the fender.

On the front end of the cover there are two strips of thick edging. Push this between the two plastic fenders where they overlap.

Take out the screw for the front of the rack there is a hole in the cover that this screw fits through. Reinstall screw through the cover and the rack.

Pull the cover into the corner snugly. Note where the plastic piece with the hole falls on the fender drill the noted area using a 11/64 drill bit, being sure not to interfere with wiring or operating components. Place the tree clips provided through the plastic in the fender cover and the drilled hole.

Reinstall seat.

## POD COVER-(FOR SOME MODELS)

Place the pod cover of the handlebars.

Note where the self-adhesive velcro falls. Remove the pod cover.

Clean noted area with isopropyl rubbing alcohol and allow to dry. Peel backing of self-adhesive velcro and adhere to area. Maximum velcro adhesion will occur in 24 hrs. at room temp.

## NOTE:

There is a flap over the auxillary power source. The power outlet may not align with the hole. If the hole does not align, cut a new hole under the flap. Cut the hole with round corners preferably a circle. This, along with the coating on the underside of the fabric will keep the material from fraying.

## WARNING

Prolonged exposure to direct sunlight may result in fading, or in severe cases, tendering of the material. Do not store your ATV with cover installed in direct sunlight. Damage resulting from exposure to direct sunlight cannot be warrantied.