

ARCTIC CAT®

Page 1 of 2

ATV CAMO BAG KIT Part #0436-390, #0436-391, #0436-392, #0436-393, #0436-394, #0436-395, #0436-566

(1 Fender Cover, 1 Tank Bag, 1 Seat Cover Kit, 1 Lunch Bag Kit & 1 Large Rack Bag)

FENDER COVER

Check for the following parts before beginning installation:

1 Instruction sheet, 1 Fender Cover, 6 Tree clips

INSTALLATION INSTRUCTIONS

1. Remove the seat, as per instruction manual.
2. Place the cover on the machine so that the warning labels are readable from the driver's seat.
3. Release all the velcro on the cover.
4. Work the front of the cover underneath the front rack and place the pockets under the front portion of the fenders.
5. On the outside bottom corners located near the footwells & wheels attach pockets to fenders.
6. Place the gear shifter through the appropriate hole in the cover.
7. Work the rear of the cover underneath the rear rack.
8. Attach all the velcro on the cover to itself. Butt the material, do not overlap the edge material adjust it so that it lays flat!
9. Be sure the pocket (that grabs the very front of the center body panel) is cupping the plastic.
10. Attach all the "J" clips around the cover to the fender.
11. On the front end of the cover there are two strips of thick edging. Push this between the two plastic fenders where they overlap.
12. Take out the screw for the front of the rack there is a hole in the cover that this screw fits through. Reinstall screw through the cover and the rack.
13. Pull the cover into the corner snugly. Note where the plastic piece with the hole falls on the fender drill the noted area using a 11/64 drill bit, being sure not to interfere with wiring or operating components. Place the tree clips provided through the plastic in the fender cover and the drilled hole.
14. Reinstall seat.

NOTE:

There is a flap over the auxillary power source. The power outlet may not align with the hole. If the hole does not align, cut a new hole under the flap. Cut the hole with round corners preferably a circle. This, along with the coating on the underside of the fabric will keep the material from fraying.

TANK BAG

Check for the following parts before beginning installation: 1 Tank Bag

INSTALLATION INSTRUCTIONS

Make sure gas tank surface is clean before installing tank cover. Any dirt on the surface will result in dulling of the finish on your ATV.

1. Remove the gas cap. place the bag on the tank, loop the nylon material around the filler neck of the tank.
2. Pull the tank cover down on each side and then hook the "J" channel onto the edge of the tank. Check for symmetry.
3. Reinstall gas cap.

Note: Make sure the tank cover is secure before operation of your ATV.

Do not carry heavy or sharp objects.

Maximum carrying capacity is 3 lbs.

SEAT COVER KIT

Check for the following parts before beginning installation: 1 Seat Cover Kit

INSTALLATION INSTRUCTIONS

1. Remove the seat, as per instruction manual.
2. Place the seat cover over the front of the seat.
3. Pull the back end of the cover over the seat.
4. Connect the velcro strap under the seat.
5. Reinstall the seat.
6. Readjust strap, if necessary.

ATV CAMO BAG KIT Part #0436-390, #0436-391, #0436-392, #0436-393, #0436-394, #0436-395, & #0436-566
(1 Fender Cover, 1 Tank Bag, 1 Seat Cover Kit, 1 Lunch Bag Kit & 1 Large Rack Bag)

LUNCH BAG KIT

Check for the following parts before beginning installation:
1 Lunch Bag Kit, 1 Foam divider, 1 Foam beverage holder

INSTALLATION INSTRUCTIONS

1. Place lunch bag on either the front or rear rack. Hooks and straps must go around corner section of the rack. This is required to hold hooks and webbing "out" to the corners.
2. Cinch strap tight - approximately 20 lbs. of pressure.
3. Fill the bag evenly, using divider to secure loose objects. Protect bag from sharp objects.

Warning: Maximum load rating is 8 lbs.


 Caution: Keep the storage bag compartment closed at all times during operation.

LARGE RACK BAG

Check for the following parts before beginning installation: 1 Large Rack Bag

INSTALLATION INSTRUCTIONS

1. Place the bag on the rack against the rack extension bar, with the handle on the bag facing away from the driver.
2. Place the "J" hooks on the appropriate bar on the rack.
3. Wrap the webbing with the attached SR buckles around the bar and back into the buckle.
4. Place the four velcro straps around the sides of the rack, and firmly secure them.

 Caution: For heavy loads or rough terrain it is recommended you use additional tie-downs. Do not carry sharp or heavy objects, maximum carrying capacity is 30 lbs.

Note: While your new Arctic Cat accessories are water resistant, they are not waterproof. It is recommended that items which must be kept dry be placed in a plastic bag or container before loading.

WARNING: Prolonged exposure to direct sunlight may result in fading and/or tendering of the material. Do not store your ATV with accessories installed in direct sunlight. Damage resulting from exposure to direct sunlight cannot be warranted.