

Arctic Cat ATV®
Installation Instructions-Accessory Kit

TBX Fender Cover Kits
(p/n 0436-786)

■ NOTE: Read these instructions thoroughly and carefully before beginning the installation process.

Retain these instructions for future reference.

Application:05-06 TBX ATV

INSTALLATION INSTRUCTIONS-FENDER COVER

It is best to have your ATV clean prior to installation

Remove the seat, as per instruction manual.

FOR FRONT FENDER (yellow reflectors):

Remove the two shoulder screws securing the two outside front rack brackets to the front fender panel. Retain hardware.

USING CAUTION: For 05 TBX-Note where the plastic piece with the hole falls on the fender. Drill out the plastic rivets on the noted area using a 11/64 drill bit. 06 TBX has appropriate hardware on ATV. Remove hardware as necessary and proceed to step 2.

Release all velcro on the cover.

Place the cover over the handlebars and rack.

With everything laid out, then slide rear of cover over "V" shaped side panels.

Attach the handlebar velcro under headlight & the velcro underneath the rack-(flap access to radiator.)

Pull the fabric forward to the headlight area. Tuck the material between the headlight and fender as seen in pic. 1.

Remove the plastic lid and storage compartment. Note where self-adhesive velcro will attach to the body panels on the inside forward of the highest point or bend in the plastic. Clean noted area with isopropyl rubbing alcohol and allow to dry. Maximum velcro adhesion will occur in 24 hrs. at room temp. Re-install plastic lids and storage compartment. See Pic 2.

FOR 05 TBX-Replace plastic rivets using provided fasteners, For 06 Replace previously removed hardware- connect the cover to the machine going through the material and into the fender. Align the pre-drilled holes in the cover (located under the two outside front rack brackets) with the bracket mounting holes: then secure the cover to the top of the fender panel removed in step 2.

Connect "J" clips to the edge of the fender.

INSTALLATION INSTRUCTIONS-REAR COVER

Place the rear cover over the rear plastic of the ATV. Note that top velcro faces 90 degrees inward from top to inside. Clean noted area as instructed above, peel backing and adhere velcro. Repeat for the bottom velcro. Maximum velcro adhesion will occur in 24hrs. at room temp.



PIC 1



PIC 2

INSTALLATION INSTRUCTIONS-POD COVER

Note where the Velcro will need to be installed. Clean noted area with isopropyl rubbing alcohol and allow to dry. Peel backing of self-adhesive Velcro and adhere to noted area. Maximum Velcro adhesion will occur in 24 hrs. at room temp.

FOR 05 TBX- Remove the 2 front plastic push rivets with needle nose pliers. Remove pod. Unplug & remove accessory plug. Place pod cover over the accessory plughole. Reinstall accessory plug and reinstall pod.

FOR 06 TBX Remove the threaded key nut. The accessory plug may be turned to the unlock position and pulled out enough to get the pod cover behind the accessory plug. Then turn the accessory plug back to the lock position-removing pod is not necessary.

Starting at the front pull the cover over the pod.

Pull the pockets at the bottom rear of the pod cover over the bottom rear plastic corners.

Adjust Velcro and seams to align with the pod contours.

Reinstall the key nut. Be careful not to twist the cover as the key nut is tightened.

NOTE:

There is a flap over the auxiliary power source. The power outlet may not align with the hole. If the hole does not align, cut a new hole under the flap. Cut the hole with round corners preferably a circle. This, along with the coating on the underside of the fabric will keep the material from fraying.

Use caution when accessing the filler neck not to spill gas on the fender cover.

WARNING

Prolonged exposure to direct sunlight may result in fading, or in severe cases, tendering of the material. Do not store your ATV with cover installed in direct sunlight. Damage resulting from exposure to direct sunlight cannot be warranted.



Printed in the U.S.A. ®™Trademarks of Arctic Cat Inc., Thief River Falls, MN 56701

0804