

ARCTIC CAT[®]

SIDE WINDSHIELD/WINDSHIELD FLAIR BAG

INSTALLATION INSTRUCTIONS

1. Remove windshield screw which secures side portion of windshield and slip tab of windshield bag between windshield and hood. Reinstall screw, making sure it passes through the hole in the tab.
2. Clean the area where the velcro is to be attached with rubbing alcohol and allow to dry. Remove the backing from the self-adhesive velcro and secure the velcro to the hood, using firm pressure from inside the bag. Maximum velcro adhesion will occur in 24 hours, at room temperature (70°F).

Note:

While your new Arctic Cat accessory is water resistant, it is not waterproof. It is recommended that items which must be kept dry be placed in a plastic bag or container before loading.

Do not carry sharp, pointed or heavy objects.

Maximum carrying capacity: 3 lbs.

IS1639396/R2

7-10-03

ARCTIC CAT[®]

SIDE WINDSHIELD/WINDSHIELD FLAIR BAG

INSTALLATION INSTRUCTIONS

1. Remove windshield screw which secures side portion of windshield and slip tab of windshield bag between windshield and hood. Reinstall screw, making sure it passes through the hole in the tab.
2. Clean the area where the velcro is to be attached with rubbing alcohol and allow to dry. Remove the backing from the self-adhesive velcro and secure the velcro to the hood, using firm pressure from inside the bag. Maximum velcro adhesion will occur in 24 hours, at room temperature (70°F).

Note:

While your new Arctic Cat accessory is water resistant, it is not waterproof. It is recommended that items which must be kept dry be placed in a plastic bag or container before loading.

Do not carry sharp, pointed or heavy objects.

Maximum carrying capacity: 3 lbs.

IS1639396/R2

7-10-03