

Arctic Cat® Snowmobile

Installation Instructions - Accessory Kit

Intake Vent Screen Covers

■ **NOTE:** Read these instructions thoroughly and carefully before beginning the installation process. Retain these instructions for future reference.

Application:
2007-2008 F-Series & Jaguar Models
2008 T-Series

Kit includes:

p/n	QTY	DESCRIPTION
4639-896	3	Intake Vent Screen Cover
1653-509	1	Instructions

1. Remove the screw securing each of the two front vent screens to the front bumper assembly; then carefully remove both vent screens.

2. Carefully remove the left-side panel vent screen.

■ **NOTE:** Prior to installing the vent screen covers, make sure to properly identify the right-side and left-side front bumper assembly covers and the left-side panel cover.

■ **NOTE:** Each of the two larger front bumper assembly covers contains a slit which will align with the lower vent tabs.

3. Place the appropriate Intake Vent Screen Cover over one of the front bumper vent screens with the vent tab inserted through the slit in the cover. Carefully reinstall the vent screen with cover and secure with existing screw. Repeat for remaining front bumper assembly vent screen.

4. Place the remaining intake vent screen cover over the left-side panel vent screen; then reinstall the vent screen making sure the elastic edge on the cover is positioned on the inside of the hood and does not interfere with the tabs securing the vent screen.

