



BRUTE FORCE FENDER POUCH INSTALLATION INSTRUCTIONS

1. Remove the rubber mesh pocket that is on the machine.
2. Place the bag in the cut-out.
3. Thread the elastic on the bag to the hooks on the fender cut-out.

CARE & CLEANING

Do not machine wash or dry. To clean, hose down thoroughly to remove all dirt. Dry accessory on machine or on a clothesline. Do not store the ATV outdoors with the accessory installed. Prolonged exposure to direct sunlight and heat can result in a breakdown of the fibers in your accessory. Damage resulting from prolonged exposure to direct sunlight cannot be warranted.

WARRANTY INFORMATION

Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for 90 days from date of purchase.
ISBRUTEPOUCHR1

1-6-06



BRUTE FORCE FENDER POUCH INSTALLATION INSTRUCTIONS

1. Remove the rubber mesh pocket that is on the machine.
2. Place the bag in the cut-out.
3. Thread the elastic on the bag to the hooks on the fender cut-out.

CARE & CLEANING

Do not machine wash or dry. To clean, hose down thoroughly to remove all dirt. Dry accessory on machine or on a clothesline. Do not store the ATV outdoors with the accessory installed. Prolonged exposure to direct sunlight and heat can result in a breakdown of the fibers in your accessory. Damage resulting from prolonged exposure to direct sunlight cannot be warranted.

WARRANTY INFORMATION

Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for 90 days from date of purchase.
ISBRUTEPOUCHR1

1-6-06



BRUTE FORCE FENDER POUCH INSTALLATION INSTRUCTIONS

1. Remove the rubber mesh pocket that is on the machine.
2. Place the bag in the cut-out.
3. Thread the elastic on the bag to the hooks on the fender cut-out.

CARE & CLEANING

Do not machine wash or dry. To clean, hose down thoroughly to remove all dirt. Dry accessory on machine or on a clothesline. Do not store the ATV outdoors with the accessory installed. Prolonged exposure to direct sunlight and heat can result in a breakdown of the fibers in your accessory. Damage resulting from prolonged exposure to direct sunlight cannot be warranted.

WARRANTY INFORMATION

Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for 90 days from date of purchase.
ISBRUTEPOUCHR1

1-6-06



BRUTE FORCE FENDER POUCH INSTALLATION INSTRUCTIONS

1. Remove the rubber mesh pocket that is on the machine.
2. Place the bag in the cut-out.
3. Thread the elastic on the bag to the hooks on the fender cut-out.

CARE & CLEANING

Do not machine wash or dry. To clean, hose down thoroughly to remove all dirt. Dry accessory on machine or on a clothesline. Do not store the ATV outdoors with the accessory installed. Prolonged exposure to direct sunlight and heat can result in a breakdown of the fibers in your accessory. Damage resulting from prolonged exposure to direct sunlight cannot be warranted.

WARRANTY INFORMATION

Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for 90 days from date of purchase.
ISBRUTEPOUCHR1

1-6-06