

ATV FENDER BAG

Part #K99994-544 (Black), #K99994-545 (Camo), #K99994-545M (Mossy Oak) & #K99994-554 (Gray)

INSTALLATION INSTRUCTIONS

- 1. Place bag on right hand side of the driver.
- 2. Connect top hook on the bag to the metal loop on the rack.
- 3. Connect bottom hooks on the bag to the fender, being sure to be clear of the footwells, suspension and wiring. Cinch tight.

CAUTION:

Do not store/carry heavy, sharp or pointed objects in the fender bag. Do not exceed maximum weight load of 5 lbs. Distribute weight evenly, and do not allow weight to shift while riding.

WARRANTY INFORMATION

Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for one year from date of purchase.

ISK99994544/45/45M/54/R2 11-10-00



Part #K99994-544 (Black), #K99994-545 (Camo), #K99994-545M (Mossy Oak) & #K99994-554 (Gray)

INSTALLATION INSTRUCTIONS

- 1. Place bag on right hand side of the driver.
- 2. Connect top hook on the bag to the metal loop on the rack.
- 3. Connect bottom hooks on the bag to the fender, being sure to be clear of the footwells, suspension and wiring. Cinch tight.

CAUTION:

Do not store/carry heavy, sharp or pointed objects in the fender bag. Do not exceed maximum weight load of 5 lbs. Distribute weight evenly, and do not allow weight to shift while riding.

WARRANTY INFORMATION

Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for one year from date of purchase.

ISK99994544/45/45M/54/R2 11-10-00