



Mule 600 Tonneau Cover

1. Mount Tonneau Cover on vehicle by inserting metal tubes into square vertical channels at front of cargo bed. Remove any debris or plastic cap if present.



2. Remove outermost bolt on lower front edge of cargo bed and reinstall with provided buckle strap and stainless steel washer as shown. Repeat this step for both sides of vehicle.



3. Tighten buckle firmly



4. Secure rear end of tonneau to vehicle after loading cargo bed by applying hook to the lower rear edge of bed. Tighten snugly by pulling on adjustment strap. Loosen by lifting on bottom edge of plastic slide.



5. Tonneau cover may be held open using supplied magnetic strap by applying to roll bar or other steel portion of cab.



6. Magnet is held in place when not in use by applying to large washer on opposing metal arch in tonneau cover.

