

Kawasaki[®] MULE

Fabric Top - Installation Instructions

1. Place fiberglass rod into gray plastic clips.
2. Snap clips onto the top side roll bars, forming an upwards bow. Center between rollbars.
3. Fit the fabric top over the metal frame.
4. Adjust the fabric top for best position and fit. The label should be positioned at the back.
5. Note where self-adhesive velcro will attach when webbing/velcro strap is tensioned to the roll cage bar.
6. Clean noted area with isopropyl rubbing alcohol and allow to dry. Peel backing of self adhesive velcro and adhere to area. Maximum velcro adhesion will occur in 24 hrs. at room temp.
7. Attach the fabric top adjust evenly on all sides. Inspect for any loose straps. Adjust to light tension.

WARNING: Remove fabric top before transport of Mule at highway speeds!

ISKAWMULE/R7



Kawasaki[®] MULE

Fabric Top - Installation Instructions

1. Place fiberglass rod into gray plastic clips.
2. Snap clips onto the top side roll bars, forming an upwards bow. Center between rollbars.
3. Fit the fabric top over the metal frame.
4. Adjust the fabric top for best position and fit. The label should be positioned at the back.
5. Note where self-adhesive velcro will attach when webbing/velcro strap is tensioned to the roll cage bar.
6. Clean noted area with isopropyl rubbing alcohol and allow to dry. Peel backing of self adhesive velcro and adhere to area. Maximum velcro adhesion will occur in 24 hrs. at room temp.
7. Attach the fabric top adjust evenly on all sides. Inspect for any loose straps. Adjust to light tension.

WARNING: Remove fabric top before transport of Mule at highway speeds!

ISKAWMULE/R7



Kawasaki[®] MULE

Fabric Top - Installation Instructions

1. Place fiberglass rod into gray plastic clips.
2. Snap clips onto the top side roll bars, forming an upwards bow. Center between rollbars.
3. Fit the fabric top over the metal frame.
4. Adjust the fabric top for best position and fit. The label should be positioned at the back.
5. Note where self-adhesive velcro will attach when webbing/velcro strap is tensioned to the roll cage bar.
6. Clean noted area with isopropyl rubbing alcohol and allow to dry. Peel backing of self adhesive velcro and adhere to area. Maximum velcro adhesion will occur in 24 hrs. at room temp.
7. Attach the fabric top adjust evenly on all sides. Inspect for any loose straps. Adjust to light tension.

WARNING: Remove fabric top before transport of Mule at highway speeds!

ISKAWMULE/R7

