



## PRAIRIE & BRUTE FORCE FENDER BAG

Part#KVF650-100, 102, 103

### INSTALLATION INSTRUCTIONS

1. Place the fender bag on the rear left side of fender.
2. Connect the velcro around the rack.
3. For the Brute Force 750: Place the webbing loop 1" above where the fender and the footwell meet. Drill a 1/8" hole and install the bolt going through the washer, hole in the webbing, plastic in fender and a washer on the underside. Connect the nut to the bolt.  
**DO NOT OVER TIGHTEN THE BOLT! BE SURE NOT TO DRILL THROUGH ANY OPERATING OR WIRING COMPONENTS!**
4. Connect the hooks to the footwell or webbing loop securely, being sure not to interfere with any wiring or operating components. Cinch tight.

**WARNING:** Maximum carrying capacity 3 lbs. Do not carry sharp or pointed objects. Direct long term exposure to sunlight may result in fading of the material. Damage resulting from exposure to direct sunlight cannot be warranted.

**WARRANTY INFORMATION:** Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for 90 days from date of purchase.

ISKVF650100/02/03/R3

1-6-06



## PRAIRIE & BRUTE FORCE FENDER BAG

Part#KVF650-100, 102, 103

### INSTALLATION INSTRUCTIONS

1. Place the fender bag on the rear left side of fender.
2. Connect the velcro around the rack.
3. For the Brute Force 750: Place the webbing loop 1" above where the fender and the footwell meet. Drill a 1/8" hole and install the bolt going through the washer, hole in the webbing, plastic in fender and a washer on the underside. Connect the nut to the bolt.  
**DO NOT OVER TIGHTEN THE BOLT! BE SURE NOT TO DRILL THROUGH ANY OPERATING OR WIRING COMPONENTS!**
4. Connect the hooks to the footwell or webbing loop securely, being sure not to interfere with any wiring or operating components. Cinch tight.

**WARNING:** Maximum carrying capacity 3 lbs. Do not carry sharp or pointed objects. Direct long term exposure to sunlight may result in fading of the material. Damage resulting from exposure to direct sunlight cannot be warranted.

**WARRANTY INFORMATION:** Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for 90 days from date of purchase.

ISKVF650100/02/03/R3

1-6-06



## PRAIRIE & BRUTE FORCE FENDER BAG

Part#KVF650-100, 102, 103

### INSTALLATION INSTRUCTIONS

1. Place the fender bag on the rear left side of fender.
2. Connect the velcro around the rack.
3. For the Brute Force 750: Place the webbing loop 1" above where the fender and the footwell meet. Drill a 1/8" hole and install the bolt going through the washer, hole in the webbing, plastic in fender and a washer on the underside. Connect the nut to the bolt.  
**DO NOT OVER TIGHTEN THE BOLT! BE SURE NOT TO DRILL THROUGH ANY OPERATING OR WIRING COMPONENTS!**
4. Connect the hooks to the footwell or webbing loop securely, being sure not to interfere with any wiring or operating components. Cinch tight.

**WARNING:** Maximum carrying capacity 3 lbs. Do not carry sharp or pointed objects. Direct long term exposure to sunlight may result in fading of the material. Damage resulting from exposure to direct sunlight cannot be warranted.

**WARRANTY INFORMATION:** Your new Kawasaki accessory is guaranteed to be free from defects in material and workmanship for 90 days from date of purchase.

ISKVF650100/02/03/R3

1-6-06