



POLARIS®

ATV FENDER BAG-2203316 INSTALLATION INSTRUCTIONS:

1. Place bag on the fender.
2. Note where velcro falls on underside of bag. Clean noted area with isopropyl alcohol and allow to thoroughly dry. Peel backing off velcro and attach to fender. Maximum velcro adhesion will occur in 24 hrs. at room temperature.
3. Feed webbing buckle strap around rack bar.
4. Attach the bottom strap to the bottom of the footwell running boards, and cinch tight.

WARNING: Fill bag evenly, DO NOT carry sharp or pointed objects. Maximum weight capacity is 3 lbs.

IS2203316R0

08/15/06



POLARIS®

ATV FENDER BAG-2203316 INSTALLATION INSTRUCTIONS:

1. Place bag on the fender.
2. Note where velcro falls on underside of bag. Clean noted area with isopropyl alcohol and allow to thoroughly dry. Peel backing off velcro and attach to fender. Maximum velcro adhesion will occur in 24 hrs. at room temperature.
3. Feed webbing buckle strap around rack bar.
4. Attach the bottom strap to the bottom of the footwell running boards, and cinch tight.

WARNING: Fill bag evenly, DO NOT carry sharp or pointed objects. Maximum weight capacity is 3 lbs.

IS2203316R0

08/15/06



POLARIS®

ATV FENDER BAG-2203316 INSTALLATION INSTRUCTIONS:

1. Place bag on the fender.
2. Note where velcro falls on underside of bag. Clean noted area with isopropyl alcohol and allow to thoroughly dry. Peel backing off velcro and attach to fender. Maximum velcro adhesion will occur in 24 hrs. at room temperature.
3. Feed webbing buckle strap around rack bar.
4. Attach the bottom strap to the bottom of the footwell running boards, and cinch tight.

WARNING: Fill bag evenly, DO NOT carry sharp or pointed objects. Maximum weight capacity is 3 lbs.

IS2203316R0

08/15/06