



RANGER 2 SOFT TOP

PARTS LIST:

1-SOFT TOP 2-FIBERGLASS RODS 4-GRAY CLIPS

INSTALLATION INSTRUCTIONS-

Note: For installation with a windshield-first install the fiberglass rods as instructed in #1 then install the windshield following the windshield instructions and last install the top.

1. Place fiberglass rods (2) into holes in gray plastic clips, then snap the clips on the top center section of the roll cage, between the 2nd and third frame bar, so that the rods are centered side to side and go front to back. If installing with a windshield the rods need to be cut approx. 1.25" and the front clamps need to be installed in an upsidedown manner to be free from the edge of the windshield.
2. Evenly drape top over frame of operators compartment so that the clear vinyl faces the back side.
3. Feed front webbing and ladderlock straps through front grab bar or under the angle reinforcement (see photo). Thread buckles, being sure to leave excess slack in webbing.
4. Feed top rear webbing and ladderlock straps through the frame post that falls behind the headrest, being sure to leave excess slack in webbing.
5. Feed bottom rear webbing and vecro straps through main frame post and under post with warning decal, being sure to leave excess slack in webbing.
6. Cinch all webbing and buckle straps evenly, being sure to keep top centered. The forward center portion should be pulled under the forward upper bar. **WARNING!** Do not allow snow or water to accumulate. Be sure to install fiberglass rods.
7. Note where the velcro pieces fall at the rear main frame posts at the sides of the clear window (2), the back bottom of the operator's compartment (4), and in the front of the windshield (1). Peel backing of self-adhesive velcro and attach to noted area. This should be done at room temperature. Maximum velcro adhesion will occur in 24 hrs.



WARNING!

Do not operate in temps. below -30. Remove if unit is to be trailered on public roads.

CARE & CLEANING

To clean, simply rinse in cold water and allow to air dry. Do not use harsh detergents, do not machine wash or dry.

OPTIONAL

Your Soft Top is equipped with a clear window. At your own discretion, the window can be disconnected and rolled up. Be sure that both rear sides are disconnected completely before attempting to roll up. Roll the window evenly. Velcro wraps are located at the top of the frame to secure rolled window.

WARRANTY INSTRUCTIONS

Your new Polaris accessory is guaranteed against any defects in material and workmanship for one full year from the date of purchase. Should any problems arise, please contact your dealer. No warranty card is necessary.