



# POLARIS®

## RANGER 2 SOFT DOOR INSTRUCTION SHEET Part #2873867

Read instructions completely before installation.

Note: To install with a windshield, it is important to proceed by first installing the doors, then the top and finally the windshield. Prior to installing the rods use a file, or sandpaper, round the ends of the fiberglass rods. Be sure to wear gloves when handling fiberglass.

### INITIAL INSTALLATION:

Remove windshield and top if already installed.

1. Install on a Ranger at room temperature only, if equipped with a Ranger top already installed; remove. The top of the doors velcro to the top of the roll cage. Install fiberglass rods into corresponding material slots sewn onto the bottom of the doors.
2. Note and measure where top front roll cage bar is fastened together, See diagram. Note: When installing Velcro, clean surface with isopropyl alcohol and allow to thoroughly dry. Peel backing off Velcro and adhere to proper area.
3. Maximum Velcro adhesion will occur in 24 hours at room temperature (65 F). Attach top portion of the door, then reinstall the top portion of the soft top being sure to feed webbing through the slots in the door, see soft top instructions. Ensure that the front snap portion of the door is flush with the wheel well before proceeding!
4. Note where the snaps fall on the inside of the wheel well when wrapped around so the webbing is inside flush with the fender. Using a 1/8" drill bit, drill noted area and pop rivet the snaps.
5. If there already has been a soft top installed use the existing velcro at the back of the roll cage. If not, use the self-adhesive velcro provided to attach the rear section of doors to the back side of the roll cage.
6. Repeat the prior instructions for the opposite side and connect the two doors.
7. Note where the velcro falls on the inside front of the roll cage near the grab handles. Peel the backing of the velcro and adhere to these areas. Note: Be sure the material cut-out is centered on the grab handle.
8. At the rear, bottom portion of the door (where the zippered portion falls) note on the inside where the velcro falls. Peel the backing and adhere to the noted area, snipping if necessary so that the velcro lays flat.
9. Note where the velcro falls at the footwells, peel the backing and adhere.
10. With the hood open, connect the J-channel to the back wall of the engine compartment.
11. Adjust the Velcro as necessary to remove any wrinkles.
12. To install the top and windshield-see the top & windshield instructions. Note the following-
13. Install windshield. Locate the mounting hardware for the windshield. (Follow instructions for mounting the windshield.)
14. Once properly located, push a hole for the windshield hardware with an awl. It is best if the awl is heated or if the hole is exposed to a heat source after punching. This will prevent fraying. Use caution not to burn material.
15. Install hardware as per windshield instructions.

**⚠ WARNING:** Do not operate in temperatures below -30 F. Align zipper as doors are closed, this will make zipping easier and allow for a longer zipper life. Keep zipper clean. Do not over tension zipper with velcro. Never trailer with soft doors installed.

### WARRANTY INSTRUCTIONS

Your new Polaris accessory is guaranteed by against any defects in material and workmanship for one full year from the date of purchase. Should any problems arise, please contact your dealer. No warranty card is necessary.

