



**Duel Rear Bags**  
**KIT P/N 2876088**

**APPLICATION:**  
**2006 – Current Sportsman X2**

This kit includes:

Qty	Part Description
1	Left Side Bag
1	Right Side Bag

**IMPORTANT:** Your Polaris accessory is designed exclusively for your vehicle. Please read the instructions thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris.

**APPROXIMATE INSTALLATION TIME:** 5 minutes

**INSTALLATION INSTRUCTIONS:**

1. Place each bag in the bed of your Sportsman X2. The mesh pocket should be on the front of each bag facing the center of the vehicle.
2. Attach the each of Velcro straps on each bag to your Sportsman X2's bed rails.

Do not carry sharp or pointed objects  
Maximum carrying capacity-5lbs. per bag



IS2876088/R0

6/13/06