



**VICTORY VISION CARGO NET
2875657**

INSTALLATION INSTRUCTIONS

Clean part with isopropyl rubbing alcohol and allow to dry.

Measure 2.25" down from the forward top edge. See pic.

Start applying the velcro at the 2.25" mark. NOTE: Front of Velcro has 2 "V"s not 3. "V"s go to the inside.

Be sure the outside edge of Velcro follows and sticks to the perimeter.

If necessary cut more relief.

Firmly press the Velcro to the part.

Attach the pocket starting from the front. (The fastener hole will be just above the velcro.) Be sure to press the Velcro on firmly and allow enough material for the corners.

Note where the fasteners will attach.

Drill with a 15/64" drill bit.

Drill the part slow and careful.

Attach the fasteners through the plastic in the net and through the hole in the plastic.

