



POLARIS®

CLOSE OFF SHOVEL BAG

PARTS LIST:

RMK SHOVEL BAG, INSTRUCTION SHEET, 4-SCREWS, 4-BOLTS

INSTALLATION INSTRUCTIONS-

Place the bag on the unit either behind the seat or behind the gas can.

The end of the shovel should face rearward.

Place bolt provided into the extruded aluminum tunnel channel.

Place the end of the bolt through the plastic on the bottom of the bag.

Install nut to the end of the bolt.

Tighten the nut to the screw.

Place the foam into the bottom of the bag.

Maximum carrying capacity 4 lbs.

ISSHOVELBAG/R0

2-20-06



POLARIS®

CLOSE OFF SHOVEL BAG

PARTS LIST:

RMK SHOVEL BAG, INSTRUCTION SHEET, 4-SCREWS, 4-BOLTS

INSTALLATION INSTRUCTIONS-

Place the bag on the unit either behind the seat or behind the gas can.

The end of the shovel should face rearward.

Place bolt provided into the extruded aluminum tunnel channel.

Place the end of the bolt through the plastic on the bottom of the bag.

Install nut to the end of the bolt.

Tighten the nut to the screw.

Place the foam into the bottom of the bag.

Maximum carrying capacity 4 lbs.

ISSHOVELBAG/R0

2-20-06



POLARIS®

CLOSE OFF SHOVEL BAG

PARTS LIST:

RMK SHOVEL BAG, INSTRUCTION SHEET, 4-SCREWS, 4-BOLTS

INSTALLATION INSTRUCTIONS-

Place the bag on the unit either behind the seat or behind the gas can.

The end of the shovel should face rearward.

Place bolt provided into the extruded aluminum tunnel channel.

Place the end of the bolt through the plastic on the bottom of the bag.

Install nut to the end of the bolt.

Tighten the nut to the screw.

Place the foam into the bottom of the bag.

Maximum carrying capacity 4 lbs.

ISSHOVELBAG/R0

2-20-06
