

INSTALLATION INSTRUCTIONS

Soft Sun Top SSV-5UG96-00-xx Rhino 660

Please read and understand these instructions completely before installation.

Dealer: These instructions contain important information for future reference, please give to customer.

1. Parts List:

Item	Part Name	Description	Qty
1	Instructions		1
2	Soft Sun Top	Polyester	1
3	Snap	Metal	2
4	Rivet	Metal	4

2. Installation:

- Measure and mark a drill point on the outside side surface of the front enclosure tubes. The drill point should be 31" above the bottom of the lower enclosure mounting area (see Photo #1, measure from "A" marked line). Drill a 1/8" size hole, and pop rivet the Snaps (Item #3) onto the vehicle.
- Place/drape Soft Sun Top (Item #2) over vehicle enclosure. The straps with button snaps should be facing forward. Snap together button snaps on Soft Sun Top to vehicle snaps installed in step 2.a. above.
- Install the buckle straps to vehicle as shown, and pull straps tight.



4. Care and Cleaning:

Do not store camo in direct sunlight, use a cover or store in shaded area. Storing in direct sunlight may result in fading of the material. Damage due to fading is not covered under the warranty. Do not machine wash or dry. Do not use harsh detergents. To clean, rinse with cold water, and allow to air dry. Do not place any items on the top when mounted. Do not allow snow or rain to accumulate on the top surface.