

ARCTIC CAT[®]

0436-436

ATV HANDLEBAR MUFFS

Check for the following parts before beginning installation:

- 1 Instruction sheet, 1 Set of handlebar muffs

INSTALLATION INSTRUCTIONS

1. Place the handlebar muff over the end of the handlebar.
2. Wrap and connect the velcro around the handlebar through the plastic buckle and back to itself.
3. Connect the remaining velcro.

WARNING

Be sure not to interfere with moving parts or operating components when installing your muffs.

Prolonged exposure to direct sunlight may result in fading, or in severe cases, tendering of the material. Do not store your ATV with the handlebar muffs installed in direct sunlight. Damage resulting from exposure to direct sunlight cannot be warranted.

IS0436436/R0

7-29-02

ARCTIC CAT[®]

0436-436

ATV HANDLEBAR MUFFS

Check for the following parts before beginning installation:

- 1 Instruction sheet, 1 Set of handlebar muffs

INSTALLATION INSTRUCTIONS

1. Place the handlebar muff over the end of the handlebar.
2. Wrap and connect the velcro around the handlebar through the plastic buckle and back to itself.
3. Connect the remaining velcro.

WARNING

Be sure not to interfere with moving parts or operating components when installing your muffs.

Prolonged exposure to direct sunlight may result in fading, or in severe cases, tendering of the material. Do not store your ATV with the handlebar muffs installed in direct sunlight. Damage resulting from exposure to direct sunlight cannot be warranted.

IS0436436/R0

7-29-02