

# Arctic Cat® ATV Installation Instructions-Accessory Kit

## Prowler Fender Cover-#0436-969

■ **NOTE:** Read these instructions thoroughly and carefully before beginning the installation process. Retain these instructions for future reference. Be sure the Prowler is clean before installation.

QTY	DESCRIPTION
1	Instruction Sheet
1	Hood Cover-1441-582
1	Front Fender Cover RH-1441-576
1	Front Fender Cover LH-1441-577
1	Rear Fender Cover RH-1441-578
1	Rear Fender Cover LH-1441-579
1	Cargo Box Fender RH-1441-580
1	Cargo Box Fender LH-1441-581

### INSTALLATION INSTRUCTIONS

#### FOR HOOD:

1. Open hood.
2. With the headlight cut outs in front, place the cover over the hood.
3. Connect the velcro under the hood.
4. Connect the side j-channels to the lip of the hood.
5. Close the hood.
6. Connect the j-channels to the front center grill area under the mesh.
7. Place the plastic tabs between the hood and headlights.

#### FOR FRONT FENDERS:

1. Place the material pocket on the top edge of the fender.
2. Place the bottom material pocket on the bottom of the fender.
3. Align the hole in the plastic with the hood latch bolt.
4. Tuck the side of the cover between the fender & the metal frame.

#### FOR REAR FENDERS:

1. Place the top material pocket over the fender.
2. Place the bottom material pockets over the fender.
3. Place the plastic tabs between the fender & the frame.

#### FOR THE REAR CARGO BOX:

1. Place the pocket with the warning label over the end of the fender.
2. Connect the top plastic tab between the fender and the cargo box.
3. Place the rear material pocket over the rear of the fender.  
HINT: To get the rear pocket over the rear of the fender it may be necessary to use a dull rounded object and pry the material around the edge of the fender.
4. Place the material pocket around the bottom of the fender.
5. Connect the j-channels to the edge of the fender.



Printed in the U.S.A. ®™Trademarks of Arctic Cat Inc., Thief River Falls, MN 56701

0804