

ARCTIC CAT®

0436-954-Advantage Timber
0436-955-Hardwoods Grey
0436-956-Max-4

Installing Fender Cover

1. Remove the seat; then remove the hardware securing the rear rack. Remove the rack. For the front rack remove the side & rear rack bolts. Leave the front bolts in.

2. Open the Velcro located near the front mesh of the fender covers; then drape the cover over the handlebar.

3. Carefully slide the cover under the front rack. Align and attach all the front velcro.

4. Attach the front 2 j-clips. Insert the plastic strips around the headlight. Place the pocket on the plastic that makes the front forward wheel well. (Inside by the headlight).

5. Note the location where the adhesive Velcro will be secured around the shift lever; then using isopropyl alcohol, clean the noted area and allow to dry. Remove the self-adhesive backing from the Velcro; then affix the Velcro to the installation area.

NOTE: Allow 24 hours for the adhesive to dry at room temperature.

6. Place the cover over the rear section. Install the J-channels around the perimeter of the ATV.

7. Where the fenders meet the footwell, remove the inner, outer, and center fender flare hardware in the area where the lower section of the cover will be installed. Re-install the hardware with the cover in place.

NOTE: The fender flare hardware must go through the cover and plastic.

8. Take note of where the adhesive Velcro will be attached under the seat and the front of the seat (for zipper opening). Using isopropyl alcohol, clean the installation area and allow to dry. Secure the Velcro to the ATV.

9. Remove the side panels. The side panels should come off with the seat. **NOTE:** Note where the holes are before installing the side panels. The drill holes are for reference only; if they do not align with the center of the O ring do not use these holes. Using an exacto knife or a razor blade make an "X" aligning with the center of the O ring. **NOTE: The cover must be cut on ATVs to allow side panels to be installed.**

10. Reinstall the racks and seat.

Installing Pod Cover

1. Temporarily position the pod cover onto the pod and take note of where the Velcro will be installed.

Remove the pod and clean the installation area with isopropyl alcohol. Allow the area to dry.

2. Remove the threaded accessory plug nut; then turn the accessory plug to the unlock position and pull outward on the plug enough to allow the pod cover to be installed under the plug.

NOTE: It is not necessary to remove the pod.

3. With the cover tucked under the plug, turn the plug back to the locked position.

4. Starting at the front, pull the cover over the pod.

5. Pull the pockets (located at the bottom rear of the pod cover) over the bottom rear plastic corners.

6. Adjust the Velcro and seams to align with the contours of the pod.

7. Carefully reinstall the nut being careful not to twist the cover as the nut is tightened.

Maintenance

1. Periodically thoroughly clean the cover and ATV to prevent dirt and debris from getting under the cover. When cleaning the cover, use a mild soap.

2. Avoid storing in direct sunlight for prolonged periods of time. When storing the ATV w/cover outside, use a storage cover.

CAUTION:

Avoid spilling gas onto the cover. Damage to the cover may occur. Avoid storing in direct sunlight for prolonged periods. Damage due to prolonged exposure cannot be warranted.



Printed in the U.S.A. ®™Trademarks of Arctic Cat Inc., Thief River Falls, MN 56701

0804