

ARCTIC CAT®

FIRECAT DASH POCKET

Part# 3639-179

T660 DASH POCKET

Part# 3639-180

M DASH POCKET

Part# 3639-717 & 4639-150 & 4639-428

T660 WINDSHIELD STORAGE BAG

Part# 3639-175 & 4639-113

Check for the following parts before beginning installation:

1 Instruction sheet, 1 Dash pocket, 2 Self-adhesive velcro


INSTALLATION INSTRUCTIONS:

1. Remove the four windshield screws.

2. Align the plastic tabs with the hole in the windshield.

3. To help locate, place your hand inside the bag and hold the end of the plastic aligning the holes. Starting with the center windshield screws, re-install the screw going through the windshield, plastic on the bag, and then the hood. After 1 center screw is done, firmly pull the bag to align the other side. Use caution not to loose the threaded rubber flange inside the engine. Repeat for the outer screws.

4. With the bag in place tensioned against the windshield using a wax pencil, or a crayon mark where the self-adhesive velcro will fall on the inside of the windshield. At room temp. clean the noted area with isopropyl rubbing alcohol and allow to dry. Peel the backing of the self-adhesive velcro and adhere to the noted area, maximum velcro adhesion will occur in 24 hrs. at room temp.

 **Caution:** Do not carry sharp or heavy objects.
Maximum carrying capacity is 2 lbs.

Note: While your new Arctic Cat accessory is water resistant, it is not waterproof.
It is recommended that items which must be kept dry be placed in a plastic bag or container before loading.

IS36391757980R3

3-24-06

ARCTIC CAT®

FIRECAT DASH POCKET

Part# 3639-179

T660 DASH POCKET

Part# 3639-180

M DASH POCKET

Part# 3639-717 & 4639-150 & 4639-428

T660 WINDSHIELD STORAGE BAG

Part# 3639-175 & 4639-113

Check for the following parts before beginning installation:

1 Instruction sheet, 1 Dash pocket, 2 Self-adhesive velcro


INSTALLATION INSTRUCTIONS:

1. Remove the four windshield screws.

2. Align the plastic tabs with the hole in the windshield.

3. To help locate, place your hand inside the bag and hold the end of the plastic aligning the holes. Starting with the center windshield screws, re-install the screw going through the windshield, plastic on the bag, and then the hood. After 1 center screw is done, firmly pull the bag to align the other side. Use caution not to loose the threaded rubber flange inside the engine. Repeat for the outer screws.

4. With the bag in place tensioned against the windshield using a wax pencil, or a crayon mark where the self-adhesive velcro will fall on the inside of the windshield. At room temp. clean the noted area with isopropyl rubbing alcohol and allow to dry. Peel the backing of the self-adhesive velcro and adhere to the noted area, maximum velcro adhesion will occur in 24 hrs. at room temp.

 **Caution:** Do not carry sharp or heavy objects.
Maximum carrying capacity is 2 lbs.

Note: While your new Arctic Cat accessory is water resistant, it is not waterproof.
It is recommended that items which must be kept dry be placed in a plastic bag or container before loading.

IS36391757980R3

3-24-06