



Parts & Accessories

Please read and understand the instructions completely before installation to avoid any possible injury to yourself or damage to the accessory or your snowmobile.

DEALER: These instructions contain important information for future reference and must be given to the customer.

1. PARTS LIST:

ITEM	PART NAME	DESCRIPTION	QTY.
1	INSTRUCTION SHEET	PAPER	1
2	YAMAHA SADDLEBAG	BALLISTIC NYLON	1
3	CAM BUCKLES	PLASTIC	4
4	RIVETS	ZINC	4

Study the illustrations thoroughly before proceeding.

2. INSTALLATION:

- Place the bag on the rear of the seat. Do not place the bag on the plastic of the rear of the seat.
- Adjust the velcro webbing straps to the preferred saddle height. *The rear should be about 2" longer than the front. The rear seat strap should sit on the very back of the seat.
- Note where the cam buckle will attach in the front of the bag on the tunnel. Using a 3/16" drill bit drill & pop rivet the cam buckle to the tunnel.

4. Connect the rear buckle strap around the bar behind the reflector.

FOR MOUNTAIN APPLICATIONS: Pull the rear strap forward and down against the tunnel.

Drill and pop rivet the cam buckle to the tunnel. Remove excess buckle if so desired using side cutters. Cut and sear excess webbing.



3. LOADING CONSIDERATIONS:

- NEVER OVERLOAD the accessory. The LOAD LIMIT is 5 lbs. per side.
- While your new accessory is water resistant it is not waterproof. In extreme conditions or with items that must be kept completely dry we suggest storing them in a plastic bag.
- DO NOT carry sharp, pointed or heavy objects.

4. CARE & CLEANING: Use a "Vacuum cleaner", sponge or cloth and clean water. Do not use detergents or harsh chemicals.

5. CUSTOMER SERVICE: See your YAMAHA dealer.

ISPHAZERSADDLES/R1

2-19-08



Parts & Accessories

Please read and understand the instructions completely before installation to avoid any possible injury to yourself or damage to the accessory or your snowmobile.

DEALER: These instructions contain important information for future reference and must be given to the customer.

1. PARTS LIST:

ITEM	PART NAME	DESCRIPTION	QTY.
1	INSTRUCTION SHEET	PAPER	1
2	YAMAHA SADDLEBAG	BALLISTIC NYLON	1
3	CAM BUCKLES	PLASTIC	4
4	RIVETS	ZINC	4

Study the illustrations thoroughly before proceeding.

2. INSTALLATION:

- Place the bag on the rear of the seat. Do not place the bag on the plastic of the rear of the seat.
- Adjust the velcro webbing straps to the preferred saddle height. *The rear should be about 2" longer than the front. The rear seat strap should sit on the very back of the seat.
- Note where the cam buckle will attach in the front of the bag on the tunnel. Using a 3/16" drill bit drill & pop rivet the cam buckle to the tunnel.

4. Connect the rear buckle strap around the bar behind the reflector.

FOR MOUNTAIN APPLICATIONS: Pull the rear strap forward and down against the tunnel.

Drill and pop rivet the cam buckle to the tunnel. Remove excess buckle if so desired using side cutters. Cut and sear excess webbing.



3. LOADING CONSIDERATIONS:

- NEVER OVERLOAD the accessory. The LOAD LIMIT is 5 lbs. per side.
- While your new accessory is water resistant it is not waterproof. In extreme conditions or with items that must be kept completely dry we suggest storing them in a plastic bag.
- DO NOT carry sharp, pointed or heavy objects.

4. CARE & CLEANING: Use a "Vacuum cleaner", sponge or cloth and clean water. Do not use detergents or harsh chemicals.

5. CUSTOMER SERVICE: See your YAMAHA dealer.

ISPHAZERSADDLES/R1

2-19-08