

## Installation Instructions WINDSHIELD BAG FOR PHAZER & PHAZER 2-UP

Please read and understand the instructions completely before installation to avoid any possible injury to yourself or damage to the accessory or your snowmobile.

DEALER: These instructions contain important information for future reference and must be given to the customer.

### 1. PARTS LIST:

ITEM	PART NAME	DESCRIPTION	QTY.
1	INSTRUCTION SHEET	PAPER	1
2	YAMAHA WINDSHIELD BAG	BALLISTIC NYLON	1

Study the illustrations thoroughly before proceeding.

### 2. INSTALLATION:

- Place the windshield bag in the area between the windshield and the top of the hood.  
See photo.
- For the 2-up: Remove the two front windshield screws and replace them going through the plastic with the hole on the bag.
- Connect the velcro around the tubes.



### 3. LOADING CONSIDERATIONS:

- NEVER OVERLOAD the accessory. The LOAD LIMIT is 2 lbs.
- While your new accessory is water resistant it is not waterproof. In extreme conditions or with items that must be kept completely dry we suggest storing them in a plastic bag.
- DO NOT carry sharp, pointed or heavy objects.

### 4. CARE & CLEANING:

Use a "Vacuum cleaner", sponge or cloth and clean water. Do not use detergents or harsh chemicals.

### 5. CUSTOMER SERVICE: See your YAMAHA dealer.

ISPHAZERWSBAG/R0

4-25-06

## Installation Instructions WINDSHIELD BAG FOR PHAZER & PHAZER 2-UP

Please read and understand the instructions completely before installation to avoid any possible injury to yourself or damage to the accessory or your snowmobile.

DEALER: These instructions contain important information for future reference and must be given to the customer.

### 1. PARTS LIST:

ITEM	PART NAME	DESCRIPTION	QTY.
1	INSTRUCTION SHEET	PAPER	1
2	YAMAHA WINDSHIELD BAG	BALLISTIC NYLON	1

Study the illustrations thoroughly before proceeding.

### 2. INSTALLATION:

- Place the windshield bag in the area between the windshield and the top of the hood.  
See photo.
- For the 2-up: Remove the two front windshield screws and replace them going through the plastic with the hole on the bag.
- Connect the velcro around the tubes.



### 3. LOADING CONSIDERATIONS:

- NEVER OVERLOAD the accessory. The LOAD LIMIT is 2 lbs.
- While your new accessory is water resistant it is not waterproof. In extreme conditions or with items that must be kept completely dry we suggest storing them in a plastic bag.
- DO NOT carry sharp, pointed or heavy objects.

### 4. CARE & CLEANING:

Use a "Vacuum cleaner", sponge or cloth and clean water. Do not use detergents or harsh chemicals.

### 5. CUSTOMER SERVICE: See your YAMAHA dealer.

ISPHAZERWSBAG/R0

4-25-06