



INSTALLATION INSTRUCTIONS

APEX WINDSHIELD POUCH

Part #SMA-8FP21-20-00

Please read and understand these instructions completely before installation to avoid injury to yourself or damage to the vehicle or accessory.

Dealer: These instructions contain important information for future reference and must be given to the customer at time of purchase or upon completion of installation.

1. Parts List

ITEM	PART NAME	DESCRIPTION	QTY
1	Instruction sheet	Paper	1
2	Windshield pouch	600d. Polyester	1
3	Self-adhesive velcro	Polyester	2

2. Installation

- Remove front windshield screws.
- Place pouch on unit.
- Install screws back through the plastic stiffener with the holes, attached to the pouch

3. Maintenance and Care

Tighten all hardware after first use and periodically thereafter.

NEVER OVERLOAD the windshield pouch. Limit 2 lbs.

DO NOT carry sharp, pointed or heavy objects, and distribute the load evenly.

Use a "Vacuum cleaner", sponge or cloth and clean water.

Do not use detergents or harsh chemicals.

⚠ WARNING

Failure to follow these installation instructions completely may void any warrantable components and result in product damage or personal injury.