



Installation Instructions VK WINDSHIELD POUCH PART#SMA-8FN21-20-00

Please read and understand the instructions completely before installation to avoid any possible injury to yourself or damage to the accessory or your snowmobile.

DEALER: These instructions contain important information for future reference and must be given to the customer.

1. PARTS LIST:

ITEM	PART NAME	DESCRIPTION	QTY.
1	INSTRUCTION SHEET	PAPER	1
2	YAMAHA WINDSHIELD POUCH	600 DENIER POLYESTER MATERIAL	1
3	VELCRO FASTENERS	POLYESTER	2

2. INSTALLATION:

- Place pouch on unit. Connect the webbing velcro straps behind the instrument panel as seen in the picture.
- Note where the press on velcro fasteners align. Clean these areas with isopropyl rubbing alcohol. Check for symmetry and attach fasteners. Adjust pouch as necessary.
- Note: For best results, install velcro at room temperature and allow 24 hrs. before loading.

3. LOADING CONSIDERATIONS:

- NEVER OVERLOAD the windshield pouch. Limit 3 lbs.
- DO NOT carry sharp, pointed or heavy objects, and distribute the load evenly.

4. CARE & CLEANING:

Use a "Vacuum cleaner", sponge or cloth and clean water.
Do not use detergents or harsh chemicals.

5. CUSTOMER SERVICE: See your YAMAHA dealer.

ISSMAVKWS/R0

2-1-05



Installation Instructions VK WINDSHIELD POUCH PART#SMA-8FN21-20-00

Please read and understand the instructions completely before installation to avoid any possible injury to yourself or damage to the accessory or your snowmobile.

DEALER: These instructions contain important information for future reference and must be given to the customer.

1. PARTS LIST:

ITEM	PART NAME	DESCRIPTION	QTY.
1	INSTRUCTION SHEET	PAPER	1
2	YAMAHA WINDSHIELD POUCH	600 DENIER POLYESTER MATERIAL	1
3	VELCRO FASTENERS	POLYESTER	2

2. INSTALLATION:

- Place pouch on unit. Connect the webbing velcro straps behind the instrument panel as seen in the picture.
- Note where the press on velcro fasteners align. Clean these areas with isopropyl rubbing alcohol. Check for symmetry and attach fasteners. Adjust pouch as necessary.
- Note: For best results, install velcro at room temperature and allow 24 hrs. before loading.

3. LOADING CONSIDERATIONS:

- NEVER OVERLOAD the windshield pouch. Limit 3 lbs.
- DO NOT carry sharp, pointed or heavy objects, and distribute the load evenly.

4. CARE & CLEANING:

Use a "Vacuum cleaner", sponge or cloth and clean water.
Do not use detergents or harsh chemicals.

5. CUSTOMER SERVICE: See your YAMAHA dealer.

ISSMAVKWS/R0

2-1-05