


Arctic Cat® UTV

Installation Instructions - Accessory Kit

Prowler Seat Cover



■ **NOTE:** Read these installation instructions thoroughly before beginning the installation process. Retain these Installation Instructions for future reference.

Application

2006-2008 Prowler/Prowler XT/XTX Models

Kit includes:

p/n	QTY	DESCRIPTION
0436-970	1	Seat Cover Assembly – Seat (2) and Headrest (2)
0453-490	1	Instructions

Installing Headrest Cover

1. Pull the elastic edge of the cover around the perimeter of the headrest. See Fig. 1.

Fig. 1




OHUV-065

2. Pull the elastic taut; then secure with the cord lock. See Fig. 1.
3. Repeat for opposite side headrest.

Installing Seat Cover

1. Remove the seat; then place the seat cover over the seat and route the velcro straps (loops) through the hole in the center bottom of the seat. See Fig. 2.


Fig. 2



OHUV-066

2. Pull the elastic edge around the perimeter of the seat to form a snug fit; then connect the velcro loops to the velcro hooks. See Fig. 3.

Fig. 3



OHUV-067

3. Install the seat.
4. Repeat for opposite side.

