

# ARCTIC CAT®

## FIRECAT EXT RACK BAG Fits Part #3639-177

Check for the following parts before beginning installation:

Instruction sheet, Rack Bag, Plastic stiffener, Foam insert, Side release buckles, Webbing/hook straps

### STIFFENER INSTALLATION:

1. Disconnect the velcro on the inside of the bag.
2. Insert the stiffener into one of the material slots sewn in the bag.
3. Pull excess material from stiffener toward the center rear of the bag to form a "U" so the other end can be inserted.
4. Place opposite end of the stiffener into the remaining material slot.
5. Work the excess of material around the contour of the bag and reconnect the velcro.
6. Place the foam in the bottom of the bag.
7. Thread the side release buckles onto the webbing straps.

### INSTALLATION INSTRUCTIONS

1. Place the bag in the rack so the logo is facing to the rear.
2. Connect the side pocket snaps together over the side rack bar.
3. **FOR 04 RACKS:** Connect the front side release buckles around the rack bar and cinch tight. **FOR 05 RACKS:** Use the hook/webbing straps from the sub-assembly kit. Thread the end of the webbing to the original male buckle and connect to the bag. Connect the end of the hook to the rear most channel on the bottom/inside of the rack. **OPTIONAL:** Cut off excess webbing extending from the female end buckle and sear end. Do not cut too close to the bag. If bag is to be used on both 04 & 05 sleds do not cut the strap.
4. On the right side of the machine in the front portion of the bag connect the velcro that is sewn to the mesh portion of the around the side rack bar.
5. Disconnect shovel.
6. Place the shovel portion of the shovel in the right hand side mesh portion of the bag and secure the end with velcro.
7. Place the shovel handle underneath the left hand side snap flap and secure, connecting the velcro around the handle.

**Note:** While your new Arctic Cat accessory is water resistant, it is not waterproof. It is recommended that items which must be kept dry be placed in a plastic bag or container before loading.

**WARNING: Do not carry sharp or heavy objects, maximum carrying capacity is 5 lbs.**

IS3639177/R2

11-4-04

# ARCTIC CAT®

## FIRECAT EXT RACK BAG Fits Part #3639-177

Check for the following parts before beginning installation:

Instruction sheet, Rack Bag, Plastic stiffener, Foam insert, Side release buckles, Webbing/hook straps

### STIFFENER INSTALLATION:

1. Disconnect the velcro on the inside of the bag.
2. Insert the stiffener into one of the material slots sewn in the bag.
3. Pull excess material from stiffener toward the center rear of the bag to form a "U" so the other end can be inserted.
4. Place opposite end of the stiffener into the remaining material slot.
5. Work the excess of material around the contour of the bag and reconnect the velcro.
6. Place the foam in the bottom of the bag.
7. Thread the side release buckles onto the webbing straps.

### INSTALLATION INSTRUCTIONS

1. Place the bag in the rack so the logo is facing to the rear.
2. Connect the side pocket snaps together over the side rack bar.
3. **FOR 04 RACKS:** Connect the front side release buckles around the rack bar and cinch tight. **FOR 05 RACKS:** Use the hook/webbing straps from the sub-assembly kit. Thread the end of the webbing to the original male buckle and connect to the bag. Connect the end of the hook to the rear most channel on the bottom/inside of the rack. **OPTIONAL:** Cut off excess webbing extending from the female end buckle and sear end. Do not cut too close to the bag. If bag is to be used on both 04 & 05 sleds do not cut the strap.
4. On the right side of the machine in the front portion of the bag connect the velcro that is sewn to the mesh portion of the around the side rack bar.
5. Disconnect shovel.
6. Place the shovel portion of the shovel in the right hand side mesh portion of the bag and secure the end with velcro.
7. Place the shovel handle underneath the left hand side snap flap and secure, connecting the velcro around the handle.

**Note:** While your new Arctic Cat accessory is water resistant, it is not waterproof. It is recommended that items which must be kept dry be placed in a plastic bag or container before loading.

**WARNING: Do not carry sharp or heavy objects, maximum carrying capacity is 5 lbs.**

IS3639177/R2

11-4-04