ARCTIC CAT®

Your new Arctic Cat Cover has been carefully manufactured of the finest quality materials available.

FEATURES: The Cover is designed to cover the entire ski and suspension area while still maintaining a custom fit. INSTALLATION:

- Place cover over handlebars first, then front of sled; finish with seat area. To remove, reverse the process. DO NOT OVER STRETCH or jerk at cover.
- 2. Wrap the velcro straps around the suspension and connect them to the cover.
- 3. Thread the middle strap through the suspension and attach it to the other side. Cinch tight.

Note: Your cover is equipped with a nylon loop in the front and 3/4" webbing and buckle straps in back for the flag to be tucked inside itself and stored easily.

Clip the 3/4" buckles around the flag pole for trailers, bend down the pole and insert it through the nylon loop, located near the front of the cover.

CARE & CLEANING: CAUTION - Do not install cover on a dirty unit. Dirt and grime may cause hood abrasion. To clean cover, use mild soap and water, rinse clean with clear water. Drip dry.

AFTER FINAL WINTER USE:

- 1. Remove tie straps and hose down thoroughly both inside and out to remove all road salt and dirt.
- 2. Reinstall cover after clothesline drying. (Do not machine dry.)

WARRANTY

Your new Cover is guaranteed against defective material and workmanship for one year from the date of its purchase. Should you have a problem of any kind, please contact your dealer. No warranty card is nesessary. Note: Damage due to "whipping" is not covered - Please be sure that your cover does not whip while trailering!

IS1639Z120/R3 10-25-05

ARCTIC CAT®

Your new Arctic Cat Cover has been carefully manufactured of the finest quality materials available.

FEATURES: The Cover is designed to cover the entire ski and suspension area while still maintaining a custom fit. INSTALLATION:

- Place cover over handlebars first, then front of sled; finish with seat area. To remove, reverse the process. DO NOT OVER STRETCH or jerk at cover.
- 2. Wrap the velcro straps around the suspension and connect them to the cover.
- Thread the middle strap through the suspension and attach it to the other side. Cinch tight.

Note: Your cover is equipped with a nylon loop in the front and 3/4" webbing and buckle straps in back for the flag to be tucked inside itself and stored easily.

Clip the 3/4" buckles around the flag pole for trailers, bend down the pole and insert it through the nylon loop, located near the front of the cover.

CARE & CLEANING: CAUTION - Do not install cover on a dirty unit. Dirt and grime may cause hood abrasion. To clean cover, use mild soap and water, rinse clean with clear water. Drip dry.

AFTER FINAL WINTER USE:

- 1. Remove tie straps and hose down thoroughly both inside and out to remove all road salt and dirt.
- 2. Reinstall cover after clothesline drying. (Do not machine dry.)

WARRANTY:

Your new Cover is guaranteed against defective material and workmanship for one year from the date of its purchase. Should you have a problem of any kind, please contact your dealer. No warranty card is nesessary. Note: Damage due to "whipping" is not covered - Please be sure that your cover does not whip while trailering!

IS1639Z120/R3 10-25-05