



Warranty Instruction Sheet WAVE RUNNER COVER

Your new Wave Runner cover is manufactured of 100% SurLast® solution dyed polyester. This custom fit cover features the Vacu-Hold strapless trailering system, and a zippered gas cap opening. It is water repellent, non-abrasive and resistant to mold, mildew, and ultra-violet rays. To clean, sponge with mild soap and cold water, rinse and allow to drip dry. Do not use harsh detergents, bleach or hot water. Do not machine wash or dry.

This cover is warranted against defects in material and workmanship for 90 days from the date of purchase. Should you have a problem of any kind, please contact your dealer. No warranty card is necessary. All that is required is the original purchase receipt.

WARRANTY LIABILITY IS LIMITED TO COVER REPLACEMENT ONLY.

The Yamaha Wave Runner covers incorporate a superior system for trailering. This unique, patented design allows the covered machine to be trailered at highway speeds **WITH NO HOLD DOWN STRAPS**. A specially engineered vacuum vent is incorporated onto the cover so that as the covered machine is trailered, a negative pressure is created to keep the cover tightly in place. No rippling, no whipping, no strap damage to hulls.

Note: Additional tie down loops are provided. These may be used when trailering behind a vehicle causing extreme turbulence or in cases of high crosswinds.

IMPORTANT: Before using this cover the first time, the elastic must be adjusted to be as tight as possible. To tighten - install cover, locate the elastic knot at the front. Pull the knot and elastic out as far as possible and retie the knot. (Large enough not to slip through the sewn edge.) Check to see that the cover can be removed and reinstalled at the rear of the machine. Trim the excess elastic 1" from the new knot and the sear edge with a cigarette lighter to prevent fraying. Remove styrofoam from vents before trailering!

Note: Some Wave Runner covers incorporate adjustable mirror pockets. If your machine is equipped with mirrors, simply unzip the mirror pockets located on either side of the front portion of the cover.

To properly install your new cover:



Fit cover over handlebars.



Pull cover over front of machine.



Pull cover over back, one side at a time.



To remove: Follow instructions in reverse order. **WARNING:** Do not remove cover from front end first!

IS2002WR/R1

6-13-05



Warranty Instruction Sheet WAVE RUNNER COVER

Your new Wave Runner cover is manufactured of 100% SurLast® solution dyed polyester. This custom fit cover features the Vacu-Hold strapless trailering system, and a zippered gas cap opening. It is water repellent, non-abrasive and resistant to mold, mildew, and ultra-violet rays. To clean, sponge with mild soap and cold water, rinse and allow to drip dry. Do not use harsh detergents, bleach or hot water. Do not machine wash or dry.

This cover is warranted against defects in material and workmanship for 90 days from the date of purchase. Should you have a problem of any kind, please contact your dealer. No warranty card is necessary. All that is required is the original purchase receipt.

WARRANTY LIABILITY IS LIMITED TO COVER REPLACEMENT ONLY.

The Yamaha Wave Runner covers incorporate a superior system for trailering. This unique, patented design allows the covered machine to be trailered at highway speeds **WITH NO HOLD DOWN STRAPS**. A specially engineered vacuum vent is incorporated onto the cover so that as the covered machine is trailered, a negative pressure is created to keep the cover tightly in place. No rippling, no whipping, no strap damage to hulls.

Note: Additional tie down loops are provided. These may be used when trailering behind a vehicle causing extreme turbulence or in cases of high crosswinds.

IMPORTANT: Before using this cover the first time, the elastic must be adjusted to be as tight as possible. To tighten - install cover, locate the elastic knot at the front. Pull the knot and elastic out as far as possible and retie the knot. (Large enough not to slip through the sewn edge.) Check to see that the cover can be removed and reinstalled at the rear of the machine. Trim the excess elastic 1" from the new knot and the sear edge with a cigarette lighter to prevent fraying. Remove styrofoam from vents before trailering!

Note: Some Wave Runner covers incorporate adjustable mirror pockets. If your machine is equipped with mirrors, simply unzip the mirror pockets located on either side of the front portion of the cover.

To properly install your new cover:



Fit cover over handlebars.



Pull cover over front of machine.



Pull cover over back, one side at a time.



To remove: Follow instructions in reverse order. **WARNING:** Do not remove cover from front end first!

IS2002WR/R1

6-13-05