

P&LARIS®

TANK BAG IQ PARTS LIST:

TANK BAG, INSTRUCTION SHEET, 2-WEBBING W/ HOLE, 2-RIVETS INSTALLATION INSTRUCTIONS-

Place the tank bag on the tank. Note where the sise release buckles are in the middle.

Adjust the velcro strap so that the hole in the d-ring assembly falls on the edge of the tunnel below the side of the seat. Be sure to mount the d-ring below the heat exchanger if applicable. Mount the d-ring as forward as possible.

Mark where the rivet will attach.

Using a 3/16" drill bit, drill & pop rivet the d-ring assembly to the tunnel.

Place the webbing at the top of the bag around the filler neck. NOTE: For the 09 IQ this is not required you may tuck the webbing underneath the bag, or cut off the webbing and sear the edge being sure not to cut the bag.

Cinch the side release buckles and adjust the velcro to keep the bag taught.

To check the gas gauge lift the end of the side release buckle and look under the main part of the bag.

Maximum carrying capacity 3 lbs.





ISIQTANKBAG/R1 4-4-08



P&LARIS[®]

TANK BAG IQ PARTS LIST:

TANK BAG, INSTRUCTION SHEET, 2-WEBBING W/ HOLE, 2-RIVETS INSTALLATION INSTRUCTIONS-

Place the tank bag on the tank. Note where the sise release buckles are in the middle.

Adjust the velcro strap so that the hole in the d-ring assembly falls on the edge of the tunnel below the side of the seat. Be sure to mount the d-ring below the heat exchanger if applicable. Mount the d-ring as forward as possible.

Mark where the rivet will attach.

Using a 3/16" drill bit, drill & pop rivet the d-ring assembly to the tunnel.

Place the webbing at the top of the bag around the filler neck. NOTE: For the 09 IQ this is not required you may tuck the webbing underneath the bag, or cut off the webbing and sear the edge being sure not to cut the bag.

Cinch the side release buckles and adjust the velcro to keep the bag taught.

To check the gas gauge lift the end of the side release buckle and look under the main part of the bag.

Maximum carrying capacity 3 lbs.





ISIQTANKBAG/R1 4-4-08